

# Tests of CF Flanges: M. Snow, Indiana

## Issues relating to CF Flanges:

NOTE: CF and VCR seals are our standard in system

- Properties of CF flanges under internal pressures are not specified by manufacturers->need for testing. What to test?
  - Internal pressure: how much can it hold?
3. Thermal cycling: will it develop a leak?
  4. How do you know the cold test was valid?

## What has been tested?

size	Flange material	O-ring material	Bolts (SS Washers)	Torques (in-lbf,size)	Internal Pressure
1.33	Al,SS	Al,Cu	Brass, SS	16,8-32 22,8-32	200 psid
2.75	Al, Ti, SS	Al,Cu	Brass, SS	62,1/4-20 96, 10-28	200 psid
4.5	SS	Cu	SS	120,5/16- 24	200 psid
6	SS	Cu	SS	120,5/16-24	200 psid
8	SS	Cu	SS	120,5-16/24	200 psid

# What was done?



He leak test at room T, 200 psid internal pressure before cold cycling in bell jar, pressure gauge connected

Thermally cycled to  $T \sim 80\text{K}$  at least 6 times while internally pressurized (T of He gas verified by P gauge)

Last cycle: removed from under LN2 bath and quickly ( $\sim 2$  min) transferred to bell jar and evacuated, leak check


Removed, heated with heat guns to room temp. reinserted and leak checked again

# Tests done at IUCF





# Tests done at IUCF



## Leak rates (all E-10 torr-l/sec)

Test rig	CF Composition (SS understood)		Leak rate initial (bkgd)	Leak rate cold	Leak rate final
A	1.33, 2.75Al, Ti, 4.5, 6		1(1)	9(8)	1(1)
B	1.33, 2.75, 6,8		2.7 (1)	91(7.7)	250 (6)
D	2.75 Al, 2.75		1(1)	1(1)	1(1)
E	1.33 Al, 1.33		1(1)	19(8.5)	11(5.1)

# What about leak plugging in air?

1. Intentionally introduce a  $4\text{E-}6$  leak at room T in a pair of 1.33 inch CF flanges with 200 psid He by loosening bolts (detect with sniffer)
2. Immerse in LN2, extract and bag immediately, get  $1.7\text{E-}5$  leak
3. Allow frost accumulation: leak =  $1.7\text{E-}5$ ,  $1.7\text{E-}5$ ,  $1.3\text{E-}5$  after 5,10,15 minutes
4. Heat to room temp, leak  $4\text{E-}6$  wet, dry

->No evidence that frost plugged this leak

## CONCLUSIONS:

1. No reason not to use Conflat flanges in system
2. Also being used at low T in other labs (JLAB)